

Smart Matter Switch





User Manual

Notes Before Installation

1. Wi-Fi only support 2.4GHz.
2. With Neutral wire or without Neutral wire.
3. Basic electrical wiring knowledge or experience is required , or please consult to a professional electrician.
4. ON/OFF button also can be used as reset button, long press any key for about 10 seconds to reset your device to factory defaults only do this if you are sure you want to erase all your settings.

Select the corresponding line diagram according to the product model you purchased.

Wiring part: As shown in the figure, please cut off the power before wiring, and do not connect with power if you are not a professional.



3.1 Add devices to Apple Home

Step1: Make sure your phone is connected to Home Pod.

Step2: Please turn on the Bluetooth and Wi-Fi of the mobile phone, and make sure that the mobile phone and your Home Pod are connected to the same WiFi.

Note: Only 2.4GHz WiFi network is supported.

The left screenshot shows the 'Speakers & TVs' section of the Home app. At the top, there is a 'Create New' button and a 'Speakers & TVs' button. Below this, there is a '办公室' (Office) section with a 'HomePod mini (2nd Gen)' device. The right screenshot shows the 'Add or Scan Accessory' menu with options: Add Scan, Add Automation, Add Room, Add People, and Add New Home.

The image is a composite of several screenshots from the 'My Home' app on an iPhone. At the top, the app's main interface is shown, featuring a 'Scan' button and a list of accessories. Below this, there are three smaller screenshots: 1. A close-up of the 'Scan' button being pressed. 2. A close-up of the 'Scan' button with a 'Scan Accessory' label. 3. A close-up of the 'Scan' button with a 'Scan Accessory' label. The bottom part of the image shows the 'Outlet' screen, which has a yellow outlet icon and a list of accessories.

Step 2: Please turn on the Bluetooth and Wi-Fi of the mobile phone, and make sure that the mobile phone and your Echo Dot are connected to the same WiFi.

Note: Only 2.4GHz WiFi network is supported.

Step 3: Power on the switch. The switch indicator light will automatically enter the fast flashing status when it is powered on.

Note: If the switch is not connected to the app for 15 minutes the indicator light will be away on. At this time, long press the reset button for about 10 seconds until the indicator light flashes, and then you can enter the pairing mode again.

The image consists of two side-by-side screenshots of an iPhone's 'SETUP' screen. The left screenshot shows the 'Which device would you like to use?' screen. At the top, it says 'No Service' and 'SETUP'. Below the title, there is a search bar labeled 'Device type or brand'. Underneath, there are 'Shortcuts' for 'ring', 'blink', 'simple', and 'matter'. The 'matter' shortcut is highlighted with a red box. Below the shortcuts, there is a list of 'All Devices' including 'Amazon Echo', 'Dash Device', and 'Light'. At the bottom, there are icons for 'Plug', 'Power', and 'Matter'. The right screenshot shows the 'Does your device have a Matter logo?' screen. It also says 'No Service' and 'SETUP'. Below the title, there is a large illustration of a hand holding a device with a Matter logo. Below the illustration, there is a question 'Does your device have a Matter logo?' and a subtext 'You can find it inside the device's box, quick-start guide or on the device.' At the bottom, there are two buttons: 'NO' and 'YES'. The 'YES' button is highlighted with a blue box.

Service 10:56 100%
SETUP

Rename Device

Use the name provided or enter a new name

Seventh plug

Service 10:54 100%
SETUP

Where is your plug?

Add your device to a group so you can control devices together and say things like, “Mama, turn on the Living Room.”

Near Groups

- Bedroom ✓
- Kitchen
- Living room
- Main bedroom

Previous Screen

Skip

Skip Update Name Add to Group

Step1: Make sure your phone is connected to Google Home Mini.

Step2: Please turn on the Bluetooth and Wi-Fi of the mobile phone, and make sure that the mobile phone and your Google Home Mini are connected to the same WiFi.

Note: Only 2.4GHz WiFi network is supported.

Step3: Power on the switch. The switch indicator light will automatically enter the fast flashing status when it is powered on.

Note: If the switch is not connected to the app for 15 minutes, the indicator light will be away on. At this time, long press the reset button for about 10 seconds until the indicator light flashes, and then you can enter the pairing mode again.

The first screenshot shows the Google Home app interface. At the top, it says 'Service' and '14:20'. Below that is a blue bar with a white 'X' icon. The main heading is 'DeVICES' in large blue letters. Underneath is a section titled 'Bedroom' with a right-pointing arrow. Below this is a light blue button labeled 'Bedroom speaker' with a right-pointing arrow. At the bottom is a red bar with a white '+ Add' button.

The second screenshot shows the 'Choose a device' screen. At the top, it says 'X' in a blue bar. The main heading is 'Choose a device' in large blue letters. Below this is a list of devices:

- A Matter-enabled device: Add devices with the Matter logo
- Google Nest or partner device: Add Nest devices, Chromecast, Google Assistant-enabled devices, or partner devices labeled "Speakers Set up with the Google Home app" (highlighted with a red box)
- Works with Google Home: List existing devices or services labeled "Works With Google Home"

 At the bottom is a red bar with a white '+ Add' button.

The image consists of two side-by-side screenshots of an iPhone screen. The left screenshot shows the 'Connect this device to your Google Account' screen. At the top, it says 'Connect this device to your Google Account'. Below that, there are three bullet points: 'This lets you control your device with Google Assistant or the Google Home app.', 'The device shares information with Google, like its current state (on/off, for example).', and 'Google may make firmware updates available when firmware updates are provided by your device manufacturer. For debugging and product improvement purposes, Google may collect device usage data and de-identified diagnostic data with the device manufacturer.' At the bottom, there is a red box around the 'Cancel' button. The right screenshot shows the 'Next, your device will be added to iOS and Google Home' screen. At the top, it says 'Next, your device will be added to iOS and Google Home'. Below that, there is a red box around the 'Sign in' button.

Next, your device will be added to iOS and Google Home

Accessory Added to "Google Home"



Done

No Service 14:35

Where is this device?

Choose a location for your . This will help you organize your devices.

My rooms

- ☒ Bedroom

Create new

Attic

Back door

Backyard

Next

Thank you for your use